


## Spare Parts Chart Retractable Air Hose Reel



Item NO.	Item Description	Quantity
1	Retainer Plate	1
2	Axle, Long Guide Roller	2
3	Short Guide Roller	2
4	Long Guide Roller	2
5	Axle, Short Guide Roller	2
6	Hex.Screw	4
7	Guide Roller Bracket	1
8	Nut, M6	11
9	Hex. Screw, M8	3
10	Guide Arm	1
11	Nut, M8	7
12	Nut, M16	1
13	Washer, M16	1
14	Square Screw	4
15	Support Base, L Type	1
16	Nut, M10	1
17	Clamp Spring	1
18	Clamp Sleeve	1
19	Clamp	1
20	Set Screw, Clamp	1
21	Axle	1
22	Clamp Base	1
23	Plastic Rotational Sleeve	1
24	Spool, Left	1
25	Spool, Right	1

Item NO.	Item Description	Quantity
26	Nut, M5	2
27	Hose Clamp	2
28	Screw	2
29	Square Screw	3
30	Set Washer, Axle	2
31	Canister, Drive Spring	1
32	Nut, M6	2
33	Bushing	1
34	Drive Spring	1
35	Cover, Drive Spring	1
36	Set Screw	2
37	Washer, M10	1
38	Clip Ring	1
39	Outlet Swivel	1
40	O-ring	2
41	Inlet Axle	1
42	Inlet Plug	1
43	Inlet Fitting	2
44	Brass Ferrule	2
45	Bend Restrictor	1
46	Rubber Hose	1
47	Hose Stopper	1
48	Lock Piece, Hose Stopper	2
49	Nut, M4	2